

# SEI Nationwide Cellular Calling Features Instructions

## Setting up 3-Way Calling

While on the first call, dial the 10-digit number of the second person.

1. Press **SEND**; the first person is automatically put on hold while the call is made.
2. When the second person answers, press **SEND** to create a conference call.
3. If the second person does not answer, press the **SEND** key twice to end the connection and go back to the first person.
4. To end both conversations, press the **END** key.

## Setting up Voice Mail on the Handset

1. Press **\*VM (\*86)**.
2. Press **SEND**.
3. If you hear a system greeting when you press **\*86 SEND**, press **#** immediately to interrupt the greeting.
4. Follow the set-up tutorial which will walk you through selecting a password, recording your personal greeting and more.

## Setting up Call Waiting

When you're on a call and a second call comes in, you'll hear a tone to let you know that you have another call. When that happens, you have two choices:

- Put the first call on hold by pressing **SEND**. You'll automatically be connected with the second call. To return to the first call, press **SEND** again. To switch between the two calls, press **SEND**.

-OR-

- End the first call by asking the first caller to hang up. This automatically connects you to your waiting call.
- To cancel Call Waiting: Before a call, dial **\*70 + the 10-digit number you are calling + SEND**.

## Call Forwarding:

1. Press **\*72**.
2. Enter the phone number where you want calls to be forwarded.
3. Press **SEND**; wait for confirmation. You should hear a confirmation tone or message.
4. Press **END**.

### To Deactivate Call Forwarding:

1. Press **\*73**.
2. Press **SEND**; wait for confirmation. You should hear a confirmation tone or message.
3. Press **END**.

## Caller ID:

In order for Caller ID to work, the called party must:

- Have a Caller ID-capable phone.
- Have the Caller ID feature activated.
- Be traveling in an area that supports Caller ID.

## Caller ID Blocking:

### To deactivate Caller ID on individual outbound calls:

1. Press **\*67**.
2. Dial the number.
3. Press **SEND**. The words "Private", "Anonymous", or some other indicator will appear on the called party's Caller ID device instead of your wireless number.

### To deactivate Caller ID on all calls to a specific number:

1. Press **\*82 + the Number + SEND**.